


# DRAPERY Battery Charging


## THINGS TO KNOW




**TYPICAL BATTERY LIFE**— This is influenced by many factors: weight, size of drape, and how many times it's operated. Unfortunately, it's very hard to tell how many times a guest opens and closes the drapes per day, so our recommendation is to charge the battery for 4 hours at a time, each quarter, or when the battery light turns red.



**THE CONNECTOR:** These motors come with an attachable battery (see arrow). You will need a charging cord (looks like a laptop charger), that connects to the battery and standard outlet when charging is needed. Note that the drape should NOT be used while charging.



**LIGHT ON MOTOR:** To avoid the accidental reprogramming of the drive, please do not touch this light/button. Light indicator on button will flash red when battery is running low.



**CHARGER LIGHT:** Plug the charger into the bottom of the battery and the LED indicator will light up as follows:

- Solid Red = Charging
- Solid Green = Charging is complete

When charging is complete, disconnect and store your charger for use at a later time.