


# ROLLER SHADE Plug & Play

## THINGS TO KNOW


### POWER




The Plug and Play motorized system uses a traditional 3-prong plug to draw power from a wall outlet. Each motor requires its own connection of 110-volt direct power.

### LOCATION

#### OUTSIDE OF WINDOW




#### INSIDE OF WINDOW




Since outlets are not typically easy to hide— if the outlet is located outside of the window opening, we recommend hiding cords behind a drape or a top treatment.

### CONTROLS

#### WALL SWITCH



#### REMOTE



Our wireless wall switches and remotes should be operated anywhere within 60 feet from the shade window. Our remote controls are battery-powered and RTS-controlled, enabling users to control their window treatments via radio waves.