



ROLLER SHADE Styles 2.0


GLOSSARY




DUAL SHADE, INSIDE MOUNTED: When two shades are mounted inside the window opening using one bracket. Requires 5.75" window opening depth.




DUAL SHADE, OUTSIDE MOUNTED: When two shades are installed together on the same bracket, but outside the opening of the wall.




TWO SHADES— ONE OUTSIDE AND ONE INSIDE MOUNTED: When one single roller shade is mounted on the wall or ceiling above the window, extending outside the window opening and another single shade is installed inside the window frame. Typically specified when the frame is too small for a dual shade bracket.



OUTSIDE MOUNTED WITH CHANNELS: When a roller shade is mounted on the wall or ceiling above the window, extending outside the window opening. Channels are on the side and sill, preventing light coming through behind the shade and window.



INSIDE MOUNTED WITH CHANNELS: When a roller shade is mounted inside the window opening and channels are installed on the side and sill of window, preventing light from coming between the shade and window frame.



COUPLED SHADES, OUTSIDE MOUNTED: When two roller shades are controlled by a single clutch or motor engaging both shades simultaneously. This requires three independent brackets, including an intermediate one for support.



THREADWELL

NO. 100125